

Home
PBXware
SERVERware
TELCOware
SIPmon
SIPProt
Desktop & Mobile
BRM
UADs
Appliances
EOL

From Bicom Systems Wiki

Contents

- **1 How to use Cisco 7961G with PBXware**
- **2 Registering Cisco 7961G**
 - **2.1 Requirements**
 - **2.2 Manual Configuration**
 - **2.3 Auto Provisioning Configuration**

How to use Cisco 7961G with PBXware

This "How to" is written as general guide on how to use Cisco 7961G with PBXware using SIP 7.1 Cisco 7961G firmware. It covers the most common tasks that are required to have your Cisco 7961G working efficiently.



Registering Cisco 7961G

Requirements

1. Cisco 7961G firmware.

- Make sure that the device is loaded with SIP 7.1 firmware.

2. DHCP server.

- Fully configured and operational DHCP server.

Manual Configuration

UAD Settings


STEP ONE: PBXware IP address.

1. Find out the IP address of PBXware server.

STEP TWO: Login to PBXware.

1. Open a new browser window and enter the IP address to access the PBXware administration interface login screen.

Example: <http://192.168.1.2>



an example with IP address

2. Hit "Enter" on your keyboard.

3. Login to PBXware with your e-mail address and password.



» Site Manager

You are currently using SSL.

Please enter your details below:

E-mail:

Password/PIN:

» Login



STEP THREE: UAD status.

1. Make sure the UAD is enabled. To check the UAD status navigate to "Settings:UAD", and click on the "edit" icon corresponding to "Cisco 7961G".

PBXware Site Settings SM Settings Help Logout







































Select a server: 127.0.0.1

Extensions
Trunks
DIDs
Conferences
IVR
Queues
Voicemail
Monitor
Reports
Settings
Servers
TBD
Protocols
Providers
Default Trunks
Networks
UAD
Destinations
Access Codes
File System
Music On Hold
MiniLCR
Sounds
Conf Files
About

Add User Agent









SIP

User Agent

AASTRA 480i		
Cisco ATA186		
Grandstream BT102		
Grandstream BT101		
Cisco 7940		
Cisco 7960		
Generic SIP		
Grandstream BT-100		
Grandstream GXP-2000		
Sipura SPA 1000		
Sipura SPA 2000		
Sipura SPA 841		
Snom 190		
Snom 320		
Grandstream HT286		
Grandstream HT486		
UTStarcom iAN-02EX		
Sipura SPA2000		
X-Lite		

IAX

User Agent

Asterisk		
Generic IAX		
Firefly		
PBXware		

ZAPTEL

UAD
Cisco 7960

Edit icon

Bicom
SYSTEMS

2. Make sure "Status" is set to "active", "Auto provisioning" is set to "No" and "DHCP" is set to "Yes".

» Device > Cisco 7960

Protocol: sip

General

DTMF Mode: rfc2833

Status: active

Network Related

NAT: Yes No Never
 Route N/A

Channels

Incoming Limit: 1

Outgoing Limit: 1

Codecs

Disallow: all

Allow: G.711 µlaw G.711 alaw
 G.723.1 G.726
 G.729 GSM
 iLBC Speex
 LPC10 H.261 Video
 H.263 Video H.263+ Video

Auto Provisioning

Auto provisioning: Yes No N/A

DHCP: Yes No N/A

Save Go back

User Agent Auto Provisioning Template:

3. Click on the "Save" button to save changes.

Creating Extension

STEP ONE: Add Extension.

1. Navigate to "Extensions". Click on "Add Extension".

PBXware Site Settings SM Settings Help Logout

Select a server: 192.168.1.2

Extensions

Trunks

DIDs

Conferences

Add Extension Search

Name	Extension	User Agent	Status	Protocol
<< left		Page 1 of 2		next >>

2. The standard options window will be shown below.

» Extensions: Add

Advanced Options

UAD: Please select..

Location: Please select..

Go back Next >

Creating Extension/Extensions Add


3. Select Cisco 7961G from "UAD" select box.

4. Select Location: "Local" or "Remote".

Note:

-"Local" is for all extensions registered on LAN.

-"Remote" is for all extensions registered from remote networks, WAN, Internet etc.



5. Click on the "Next" button.

STEP TWO: Extension values.

1. Enter values into the required field text boxes.


REQUIRED FIELDS:

Name:

Enter a name for the extension being created. **Example:** John Smith.


E-mail:

Enter the e-mail address associated with this extension. This e-mail address will receive all system notification messages. **Example:** john@domain.com.



an example with details filled in

2. Click on the "Save" button.



an example with details filled in

3. Click on the "Save & E-mail" button. Account details will be sent to the e-mail address associated with this extension.

OPTIONAL FIELDS:

Extension:

An auto-generated extension number based on the next available sequential number. An extension value can be changed. **Example:** 1000.

Username:

Username is auto generated/populated and cannot be changed since it allows the system to use this value for other important operations.

Secret:

A secret value associated with the UAD is auto-generated in order to allow the UAD to successfully register with the system. The secret value can be changed.

PIN:

An auto-generated PIN will allow access to voicemail and online self care.

Registering Phone

STEP ONE: Electricity and Ethernet.

Note: Phone electricity can be supplied by power adaptor or power over ethernet injector.

A) Power adapter.

1. Plug the power adapter into a power jack then connect it to the electricity network.
2. Connect the ethernet port to a hub, router or switch as to access LAN.



B) Power over ethernet.

1. Connect the ethernet port to a "POE Passive Power over Ethernet injector".
2. Connect "POE Passive Power over Ethernet injector" to a hub, router or switch as to access LAN.



After successfully connecting the Cisco 7961G to the electricity and data networks, it is time to register it to PBXware.

STEP TWO: Cisco 7961G settings configuration.



Unlock configuration:

1. Press the "settings" button.
2. Use the "navigation" button and navigate down to "Unlock Config".
3. Press the "Select" button.
4. Enter password (Default factory password is "cisco").
5. Press the "Accept" button to unlock configuration.

SIP Configuration

1. Use the "navigation" button and navigate up to "SIP Configuration".
2. Press the "Select" button.
3. Press the "Select" button to enter into "Line 1 Settings".
4. Enter the details into:

REQUIRED FIELDS:

Name

Cisco 7961G extension number. **Example:** 1000.

Authentication Name

Usually the same number as "Name".

Authentication Password

The Secret of the extension as received in the e-mail associated with this extension. **Example:**

3dX3r5

Proxy Address

IP address of PBXware server. **Example:** 192.168.1.2

OPTIONAL FIELDS

Shortname

Example: John Smith, Reception, Entrance Main, Agent One etc.

Display Name

Example: John Smith, Reception, Entrance Main, Agent One etc.

Proxy Port

By default 5060

5. Press the accept button and reboot Cisco 7961G.

- Conclusion: If everything is done as above described you should have successfully registered your Cisco 7961G to PBXware. Dial ***123** to verify registration.

- For further information, please contact the manufacturer or check their web site www.cisco.com.

Auto Provisioning Configuration

'UAD Settings


STEP ONE: PBXware IP address.

1. Find out the IP address of PBXware server.

STEP TWO: Login into PBXware.

1. Open a new browser window and enter the IP address to access the PBXware administration interface login screen.

Example: <http://192.168.1.2>



an example with IP address

2. Hit "Enter" on your keyboard.
3. Login to PBXware with your e-mail address and password.



» Site Manager

You are currently using SSL.

Please enter your details below:

E-mail:

Password/PIN:

» Login



STEP THREE: UAD status.

1. Make sure the UAD is enabled. To check the UAD status navigate to "Settings:UAD", and click on the "edit" icon corresponding to "Cisco 7961G".

PBXware Site Settings SM Settings Help Logout

Select a server: 127.0.0.1

- Extensions
- Trunks
- DIDs
- Conferences
- IVR
- Queues
- Voicemail
- Monitor
- Reports
- Settings**
 - Servers
 - TBD
 - Protocols
 - Providers
 - Default Trunks
 - Networks
 - UAD**
 - Destinations
 - Access Codes
 - File System
 - Music On Hold
 - MiniLCR
 - Sounds
 - Conf Files
 - About

UAD
Cisco 7960

Edit icon

Bicom
SYSTEMS

[Add User Agent](#)

SIP

User Agent	Tools
AASTRA 480i	[Edit] [Delete]
Cisco ATA186	[Edit] [Delete]
Grandstream BT102	[Edit] [Delete]
Grandstream BT101	[Edit] [Delete]
Cisco 7940	[Edit] [Delete]
Cisco 7960	[Edit] [Delete]
Generic SIP	[Edit] [Delete]
Grandstream BT-100	[Edit] [Delete]
Grandstream GXP-2000	[Edit] [Delete]
Sipura SPA 1000	[Edit] [Delete]
Sipura SPA 2000	[Edit] [Delete]
Sipura SPA 841	[Edit] [Delete]
Snom 190	[Edit] [Delete]
Snom 320	[Edit] [Delete]
Grandstream HT286	[Edit] [Delete]
Grandstream HT486	[Edit] [Delete]
UTStarcom iAN-02EX	[Edit] [Delete]
Sipura SPA2000	[Edit] [Delete]
X-Lite	[Edit] [Delete]

IAX

User Agent	Tools
Asterisk	[Edit] [Delete]
Generic IAX	[Edit] [Delete]
Firefly	[Edit] [Delete]
PBXware	[Edit] [Delete]

ZAPTEL

2. Make sure "Status" is set to "active", "Auto provisioning" is set to "Yes" and "DHCP" is set to "Yes".

» Device > Cisco 7960

Protocol: sip

General

DTMF Mode: rfc2833

Status: active

Network Related

NAT: Yes No Never
 Route N/A

Channels

Incoming Limit: 1

Outgoing Limit: 1

Codecs

Disallow: all

Allow: G.711 µlaw G.711 alaw
 G.723.1 G.726
 G.729 GSM
 iLBC Speex
 LPC10 H.261 Video
 H.263 Video H.263+ Video

Auto Provisioning

Auto provisioning: Yes No N/A

DHCP: Yes No N/A

Save Go back

User Agent Auto Provisioning Template:

3. Click on the "Save" button to save changes.

Creating Extension

STEP ONE: Add Extension.

1. Navigate to "Extensions". Click on "Add Extension".

PBXware Site Settings SM Settings Help Logout

Select a server: 192.168.1.2

Extensions

Trunks

DIDs

Conferences

Add Extension Search

Name	Extension	User Agent	Status	Protocol
<< left		Page 1 of 2		next >>

2. The standard options window will be shown below.

» Extensions: Add

Advanced Options

UAD: Please select..

Location: Please select..

Go back Next >

Creating Extension/Extensions Add


3. Select Cisco 7961G from "UAD" select box.

4. Select Location: "Local" or "Remote".

Note:

-"Local" is for all extensions registered on LAN.

-"Remote" is for all extensions registered from remote networks, WAN, Internet etc.



Creating
Extension/Extensions Add

5. Click on "Next" button.

STEP TWO: Extension values.

1. Enter values into required field text boxes.

REQUIRED FIELDS:

Name:

Enter a name for the extension being created. **Example:** John Smith.

E-mail:

Enter the e-mail address associated with this extension. This e-mail address will receive all system notification messages. **Example:** john@domain.com.

Auto provisioning:

Set to "Yes".

MAC Address:

Cisco 7961G MAC address. **Example:** 001646f5f797



Creating
Extension/Extensions Add

an example with details filled in

2. Click on the "Save" button.



Creating Extension

an example with details filled in

3. Click on the "Save & E-mail" button. Account details will be sent to the e-mail address associated with this extension. **OPTIONAL FIELDS:**

Extension:

An auto-generated extension number based on the next available sequential number. An extension value can be changed. **Example:** 1000.

Username:

Username is auto generated/populated and cannot be changed since it allows the system to use this value for other important operations.

Secret:

A secret value associated with the UAD is auto-generated in order to allow the UAD to successfully register with the system. The secret value can be changed.

PIN:

An auto-generated PIN will allow acces

Registering Phone

STEP ONE: Electricity and Ethernet.

Note: Phone electricity can be supplied by power adaptor or power over ethernet injector.

A) Power adapter.

1. Plug the power adapter into a power jack then connect it to the electricity network.
2. Connect the ethernet port to a hub, router or switch as to access LAN.



B) Power over ethernet.

1. Connect the ethernet port to a "POE Passive Power over Ethernet injector".
2. Connect "POE Passive Power over Ethernet injector" to a hub, router or switch as to access LAN.



"TFTP Server" must be set with TFTP server value.

STEP TWO: Cisco 7961G TFTP configuration.



Unlock configuration:

1. Press the "settings" button.
2. Use the "navigation" button and navigate down to "Unlock Config".
3. Press the "Select" button.
4. Enter password (Default factory password is "cisco").
5. Press the "Accept" button to unlock configuration.

SIP Configuration

1. Use the "navigation" button and navigate up to "Network Configuration".
2. Press the "Select" button.
3. Navigate down to "TFTP server".
4. Press the "Select" button to edit TFTP value.
5. Enter details into TFTP value field.
6. Press accept button and reboot Cisco 7961G.

- Conclusion: If everything is done as above described you should have successfully registered Cisco 7961G to PBXware. Dial ***123** to verify registration.

- For further information, please contact the manufacturer or check their web site www.cisco.com.

Retrieved from "http://wiki.bicomsystems.com/Cisco_7961G"