

Home  
PBXware  
SERVERware  
TELCOware  
SIPmon  
SIPProt  
Desktop & Mobile  
BRM  
UADs  
Appliances  
EOL

## From Bicom Systems Wiki

This site contains list of UADs supported in PBXware 6.0, also on this page you will find user manuals for these devices.

Please note that devices marked with RED color are no longer supported but will remain on the UAD list.

**Yealink**

T18P
T19P
T20P
T21PE2
T22P
T23G
T26P
T27P
T27G
T28P
T29G
T30
T30P
T31
T31P
T31G
T32G
T33P
T33G
T38G
T40G
T41P
T41S
T42G
T42S
T41U
T42U
T43U
T46U
T48U
T46G
T46S
T48G
T48S

**Yealink**

T49G
T52S
T53W
T53
T54S
T54W
T56A
T57W
T58V
VP59
CP860
CP920
CP930W
CP960
T60P
T65P
W52P
W53H
W56P
W60B
W70B
W80B
W90DM

**Polycom**

Poly Trio C60
Poly Trio 8300
VVX 101
VVX 150
VVX 201
VVX 250
VVX 300
VVX 310
VVX 350
VVX 400
VVX 410
VVX 411
VVX 450
VVX 500
VVX 501
VVX 501
VVX 601
VVX 1500
VVX 150 OBi Edition
VVX 250 OBi Edition
VVX 350 OBi Edition
VVX 450 OBi Edition

**VTech**

ET 605
ET 617
ET 635
ET 685
VDP 650
VSP 600
VSP 715
VSP 716A
VSP 725
VSP 726
VSP 726A
VSP 735
VSP 736
VSP 736A
VCS 754

**Snom**

D120
D315
D335
D345
D375
D385
D715
D717
D735
D745
D765
D785
M300
M900
190
320
360
710

**Grandstream**

DP750
DP752
GXP-1615
GXP-1625
GXP-1628
GXP-1630
GXP-1760W
GXP-1782
GXP-2130
GXP-2135
GXP-2140
GXP-2160
GXP-2170
GRP-2612
GRP-2613
GRP-2614
GRP-2615
GXV-3240
GXV-3275
GXV-3350
GXV-3370
GXV-3380
GXP-2000
GXP-2124

**Fanvil**

H3
H5
X2P
X3SP
X4
X4G
X3U
X4U
X5U
X6U
X5S
X6
X7
X7C
X210

**Cisco**

6851
7821
8841
8851
8865
7940
7941G
7942G
7945G
7960
7961
7962
7965G
7971G
7975G

**Gigaset**

N510
N720
N870
Maxwell Basic
Maxwell 2
Maxwell 3
Maxwell 4
Maxwell 10

**Cisco Spa**

SPA301
SPA501G
SPA502G
SPA504G
SPA508G
SPA509G
SPA514G
SPA525G2
SPA901

**HTek**

UC802
UC803
UC804
UC806
UC840
UC842
UC860
UC862
UC902P
UC903
UC912P
UC912G
UC923
UC924
UC924E
UC926
UC926E

**Sangoma**

S500
S505
S700
S705

**Alcatel**

Alcatel Lucent M3
Alcatel Lucent M7
Alcatel Lucent H6
Alcatel Lucent H3G
Alcatel Lucent H2P

**Obihai**

OBi 1022
OBi 1032
OBi 1062

**Huawei**

eSpace 7910
eSpace 7950

**PHONES**

**ATAs**

<b>Aastra</b>	53i	55i	57i	480i	9112i	9133i
			6867i			
	<b>Denwa</b>	<b>Panasonic</b>	<b>Linksys</b>	<b>Sipura</b>		
		KX-HDV130				
		KX-HDV230C				
		KX-HDV330C				
	<b>Mitel</b>	KX-UT113	SPA-941			
		KX-UT123	SPA-942	SPA-841		
		KX-UT133	SPA-962			
		KX-UT136				
		KX-TGP550				
		KX-UTG300B				

<b>Obihai</b>	<b>Grandstream</b>	<b>Grandstream</b>	<b>Sipura</b>	<b>Cisco</b>	<b>Linksys</b>	<b>ReadyNet</b>	<b>Snom</b>
	HT-802	HT-496				AC1000MS	
	HT-814	HT-502				AC1100MSF	
	HT-818	HT-503	SPA-1000			AC1200MS	
OBI110	BT-102	HT-701	SPA-2000	SPA112	Linksys PAP2		PA1
OBI202	BT-101	HT-702	SPA-3000		SPA8000		
OBI300	HT-286	HT-704					
OBI302	HT-386	GXW-4004					
OBI504	HT-486						
OBI508	HT-488						
	HT-496						

**EXPANSION MODULES**

**PCI CARDS**

<b>Yealink</b>	<b>Digitum</b>
EXP40	TDMXXX
EXP50	TE110P
	TE205P
	TE405P
	TE406P
	TE410P
	TE411P

**DECT HANDSETS**

<b>Snom</b>
M25
M80

Retrieved from "[http://wiki.bicomsystems.com/Business\\_6\\_End\\_Points](http://wiki.bicomsystems.com/Business_6_End_Points)"

---

Disclaimers - About Bicom Systems Wiki