

Home
PBXware
SERVERware
TELCOware
SIPmon
SIPProt
Desktop & Mobile
BRM
UADs
Appliances
EOL

From Bicom Systems Wiki

This site contains list of UADs supported in PBXware 3.8, also on this page you will find user manuals for these devices.

Contents

- **1 Supported UAD List**
 - **1.1 Polycom**
 - **1.2 Yealink**
 - **1.3 Cisco**
 - **1.4 Cisco SPA**
 - **1.5 Linksys**
 - **1.6 Sipura**
 - **1.7 Aastra**
 - **1.8 Snom**
 - **1.9 Grandstream**
- **2 User Manuals**
 - 2.1 Polycom
 - 2.2 Yealink
 - 2.3 Cisco
 - 2.4 Linksys
 - 2.5 Sipura
 - 2.6 Aastra
 - 2.7 Snom
 - 2.8 Grandstream
 - 2.9 xten_networks
 - 2.10 Digium

Supported UAD List

Polycom

- Polycom IP 301
- Polycom IP 320
- Polycom IP 321
- Polycom IP 330
- Polycom IP 331
- Polycom IP 335
- Polycom IP 550
- Polycom IP 501
- Polycom IP 550
- Polycom IP 560
- Polycom IP 601
- Polycom IP 650
- Polycom IP 670

Yealink

- Yealink T18P
- Yealink T20P
- Yealink T22P
- Yealink T26P
- Yealink T28P
- Yealink T32P
- Yealink T38P
- Yealink T42G
- Yealink T60P
- Yealink T65P
- Yealink W52P

Cisco

- Cisco 7940
- Cisco 7941G
- Cisco 7942G
- Cisco 7945G
- Cisco 7960
- Cisco 7961
- Cisco 7962
- Cisco 7965G
- Cisco 7971G
- Cisco 7975G

Cisco SPA

- Cisco SPA301
- Cisco SPA501G
- Cisco SPA502G
- Cisco SPA504G
- Cisco SPA508G
- Cisco SPA509G
- Cisco SPA525G

- Cisco SPA901

Linksys

- Linksys SPA-941
- Linksys SPA-942
- Linksys SPA-962

Sipura

- Sipura SPA-841

Sipura ATA devices

- Sipura SPA-1000
- Sipura SPA-2000
- Sipura SPA-3000

Aastra

- Aastra 480i
- Aastra 53i
- Aastra 55i
- Aastra 57i
- Aastra 9112i
- Aastra 9133i

Snom

- Snom 190
- Snom 320
- Snom 360

Grandstream

- Grandstream GXP-2000
- Grandstream GXW-4004

Grandstream ATA devices

- Grandstream BT-102
- Grandstream BT-101
- Grandstream HT-286
- Grandstream HT-386
- Grandstream HT-486
- Grandstream HT-488
- Grandstream HT-496
- Grandstream HT-502
- Grandstream HT-503
- Grandstream HT-701

User Manuals

Polycom

Phones

Polycom user manual PDF

Yealink

Phones

Yealink user manual PDF

Cisco

Phones

Cisco 7940 PDF

Cisco 7960 PDF

Cisco SPA devices PDF

Linksys

Phones

Linksys SPA941 PDF

Linksys SPA942 PDF

Linksys SPA962 PDF

Sipura

Phones

Sipura SPA841 PDF

ATA Devices

Sipura SPA1000 PDF

Sipura SPA2000 PDF

Sipura SPA2002 PDF

Sipura SPA2100 PDF

Sipura SPA3000 PDF

Aastra

Phones

Aastra 480i PDF

Aastra 53i PDF

Aastra 55i PDF

Aastra 57i PDF

Aastra 9112i PDF

Aastra 9133i PDF

Snom

Phones

Snom 320 PDF

Snom 360 PDF

Grandstream

Phones

Grandstream BT-101/BT-102 PDF

Grandstream BT-200 PDF

Grandstream GXP-2000 PDF

ATA devices

Grandstream HT-286 PDF

Grandstream HT-386 PDF

Grandstream HT-486 PDF

Grandstream HT-488 PDF

Grandstream HT-496 PDF

xten_networks

Softphones

X-Lite PDF

X-Pro PDF

Digium

PCI cards

TDMXXX PDF

TE110P PDF

TE205P PDF

TE405P PDF

TE406P PDF

TE410P PDF

TE411P PDF

Next -> 21. Dynamic Auto Provisioning

Retrieved from "http://wiki.bicomsystems.com/MT_3.8.5_End_Points"

Disclaimers - About Bicom Systems Wiki