

Home  
PBXware  
SERVERware  
TELCOware  
SIPmon  
SIPProt  
Desktop & Mobile  
BRM  
UADs  
Appliances  
EOL

## From Bicom Systems Wiki

**IMPORTANT: PBXware 3.8 has reached its END OF LIFE status. Please bear in mind that limited support will be available until June 30th, 2020.**

PBXware is a scalable telephony solution featuring a range of traditional telephony and emerging VoIP technologies. The creation of a national/global voice networks in addition to a complete range of Analog, Digital, and VoIP channels, all fully supported. Functionality includes: Voicemail, IVR, ACD Queues, Call recording/monitoring, Conferences, Auto Provisioning/Configuration and much more.

1. Getting Started
2. System Overview
3. Extensions
4. Trunks
5. DID
6. Conferences
7. IVR
8. Queues
9. Agents
10. Voicemail
11. Monitor
12. Networks
13. Reports
14. Statistics
15. Fax
16. System
17. Routes
18. LCR
19. Service Plans
20. Settings
21. Site Settings
22. End Points
23. Dynamic Auto Provisioning
24. Glossary

Retrieved from "[http://wiki.bicomsystems.com/PBXware\\_3.8\\_Administration\\_Manual](http://wiki.bicomsystems.com/PBXware_3.8_Administration_Manual)"

---

Disclaimers - About Bicom Systems Wiki