

Home  
 PBXware  
 SERVERware  
 TELCOware  
 SIPmon  
 SIPProt  
 Desktop & Mobile  
 BRM  
 UADs  
 Appliances  
 EOL

## From Bicom Systems Wiki

This site contains list of UADs supported in PBXware 3.8, also on this page you will find user manuals for these devices.

PHONES					ATAs	SOFT PHONES	PCI CARDS
				<b>Polycom</b>			
				IP 301			
				IP 320			
				IP 321			
				IP 330			
				IP 331			
				IP 335			
				IP 450			
				IP 501			
				IP 550			
				IP 560			
				IP 601			
				IP 650			
				IP 670			
				IP 5000			
					<b>Yealink</b>		
					T18P		
					T20P		
					T22P		
					T26P		
					T28P		
					T32G		
					T38G		
					T41P		
					T42G		
					T46G		
					W52P		
						<b>Grandstream</b>	
						BT-102	
						BT-101	
						HT-286	
						HT-386	
						HT-486	
						HT-488	
						HT-496	
						HT-502	
						HT-503	
						HT-701	
							<b>Digium</b>
							TDMXXX
							TE110P
							TE205P
							TE405P
							TE406P
							TE410P
							TE411P
						<b>Sipura</b>	
						SPA-1000	
						SPA-2000	
						SPA-2002	
						SPA-2100	
						SPA-3000	
							<b>Xten Networks</b>
						X-Lite	
						X-Pro	
<b>Aastra</b>							
480i	7941G	<b>Cisco SPA</b>					
53i	7942G	SPA301					
55i	7945G	SPA501G					
57i	7960	SPA502G	<b>Grandstream</b>	<b>Linksys</b>	<b>Sipura</b>	<b>Snom</b>	
9112i	7961	SPA504G	GXP-2000	SPA-941	SPA-841	320	
9133i	7962	SPA508G		SPA-942		360	
	7965G	SPA509G		SPA-962			
	7971G	SPA525G					
	7975G						

Next -> 23.Dynamic Auto Provisioning

Retrieved from "http://wiki.bicomsystems.com/PBXware\_3.8\_End\_Points"