


Home
PBXware
SERVERware
TELCOware
SIPmon
SIPProt
Desktop & Mobile
BRM
UADs
Appliances
EOL

From Bicom Systems Wiki

The LCR (Least Cost Routing) section allows fine tuning of the system's trunks usage accordingly to the price and quality. By default, the system uses default trunks for each destination in order to present this feature as simply as possible.

▪ **Routes:**



Displays all available destination routes alphabetically.

(ex. A, B, C, D...)

(Button)

▪ **Destination group:**

Further description of the selected route. Displays destinations by proper, mobile number, etc

Example:

- Special Service
- 48 States
- Toll Free
- Alaska
- Hawaii

(Display)

▪ **Primary/Secondary/Tertiary Trunk:**

Select trunks to be used to desired destination

(ex. Voip trunk)

(Select box)

Precedence

Settings:

- Default Trunks: All System calls go through trunks defined here
- MiniLCR: Overrides 'Default Trunks' and sets a specific trunk for a destination

Extensions:

- Trunks: Overrides **Settings -> Default Trunks**
- Routes: Overrides **Settings -> MiniLCR**

Next -> 20. Service Plans

Retrieved from "http://wiki.bicomsystems.com/PBXware_5.3_LCR"