


Home
PBXware
SERVERware
TELCOware
SIPmon
SIPProt
Desktop & Mobile
BRM
UADs
Appliances
EOL

From Bicom Systems Wiki

Description:



Caller ID	
Trust Remote-Party-ID:	<input checked="" type="radio"/> Yes <input type="radio"/> No <input type="radio"/> Not Set
Send Remote-Party-ID:	<input type="text" value="Use Remote-Party-ID"/>
Send Caller ID in RPID for Anonymous calls:	<input type="radio"/> Yes <input type="radio"/> No <input checked="" type="radio"/> Not Set
Connected Line Updates:	<input checked="" type="radio"/> Yes <input type="radio"/> No <input type="radio"/> Not Set
RPID with SIP UPDATE:	<input checked="" type="radio"/> Yes <input type="radio"/> No <input type="radio"/> Not Set

In order to display a Caller ID when picking up the call from Call Parking, users need to set the options as follows:


- **Trust Remote-Party-ID:** 'Yes'
- **Send Remote-Party-ID:** 'Use Remote-Party-ID'
- **Connected Line Updates** 'Yes'
- **RPID with SIP UPDATE:** 'Yes'

To access the settings, navigate to 'Tenant' → 'Extensions' → the 'Caller ID' section.

For more information, please refer to the screenshot.

Also, users should log in to the phone's GUI and set the following option as shown below:

- **Caller ID Source:** 'RPID-PAI-FROM'



Caller ID Source	<input type="text" value="RPID-PAI-FROM"/>
------------------	--

To access the settings for Yealink phones, please navigate to 'Account' → 'Advanced' → 'Caller ID Source'.

NOTE: Mentioned settings need to be set on all Extensions included in the call flow.

Retrieved from "http://wiki.bicomsystems.com/HOWTO_Display_a Caller_ID_on_Call_Parking"

Disclaimers - About Bicom Systems Wiki